

Introduction

To determine the size of a DPI for an application it is necessary to have data on the load to be supported. The accuracy of the data collected will depend on the technical expertise and measuring instruments that are available on site.

Load parameters

The most accurate result will be obtained when the first three parameters listed are measured on site. The up-time value will depend on the application requirements. It generally falls in the range 0.35 to 3 seconds and is user adjustable from 0.1 to 3.1 seconds in 0.1 second steps. The factory default for this parameter is 1 second.

1. Load voltage (V_{supply})
2. Load current (I_{load})
3. Load power factor ($\cos\Phi$)
4. Up-time (t) Factory default setting 1 second

Methods to determine the electrical parameters

1. Measure the values

The best method to determine the load parameters is to measure them on site. Use a true rms multimeter with a current probe that can measure power factor for the measurements (eg Fluke 39). See Fig 1 for measurement points.

2. Load based estimate

The *continuous* load (VA) or current (A) rating of the devices to be supported should be added together. This information can be found on a schematic diagram of the control circuit in the motor control center (MCC) or switchboard, or from the device manufacturer. Add up the *holding* VA of each contactor *coil* to obtain the total load VA and note the coil/control voltage. The contactor energizing or inrush current need not be considered. Load current is equal to the load VA divided by the load voltage. The load power factor must be estimated. If the load is all contactors and relays use a power factor of 0.2. Check for resistive loads such as PLC power supplies signal lamps or other electronic devices and if these are present use a power factor of 0.75.

3. Control transformer rating

The size of the control transformer(s) can be found on the transformer rating label. Make a note of the VA rating and the secondary voltage (control voltage). The control voltage will normally be 120, 208 or 230Vac. Load current is equal to the transformer VA rating divided by the transformer secondary voltage. The load power factor must be estimated. If the load is all contactors and relays use a power factor of 0.2. Check for resistive loads such as PLC power supplies signal lamps or other electronic devices and if these are present use a power factor of 0.75.

Up-time value

The factory default setting of 1 second will work well with most applications. There are situations where it is necessary to reduce the up-time and others where it is beneficial to increase it. The optimum up-time depends on the application.

1. Low inertia loads require shorter up-times

Large compressors and pumps slow down very rapidly when power is removed and it is considered unsafe to hold the controls in for longer than 350ms. See *Two level*

Guidelines for sizing a DPI

timer option for more details on compressor and pump applications.

2. High inertia loads use longer up-times

Conveyers and fans are high inertia loads and can run for seconds after the power has been removed. Up-times of 2 to 3 seconds can be used for these applications.

3. Non rotating loads use longer up-times

Boiler and gas oven controls can be held in for longer times and can use up-time settings from 2 to 3 seconds or longer.

Select a DPI based on application data

1. Use the on line DPI Selector

The easiest and most accurate way to select a DPI is to use the on line DPI Selector on our web site (www.dipproof.com/products/dpi_selector.asp). Enter the figures for Load current, Load voltage, Load power factor and Required Up-time, then click Select DPI. The DPI Selector will display two or three models based on the figures entered. The DPI that most closely matches the application criteria is indicated by a "star", this is the model to use for the application.

Example:

Application data: $t = 1 \text{ second} / V_{\text{supply}} = 120\text{V} / I_{\text{load}} = 10\text{A} / \cos \Phi = 0.2$

Enter these figures in the on line DPI Selector.

SS switching systems

Welcome to the Switching Systems' website Home Product Information Company Profile Contact Us

DPI Selector

Please enter the application values into the fields below, then click on "Select DPI" to list units that most accurately match your criteria.

If Power Factor is not known check the load:
Power supplies, resistors, lamps - $\cos \phi = 1$
Contactors & relays only - $\cos \phi = 0.2$
Mixed loads estimate or use - $\cos \phi = 0.75$

Measure $\cos \phi$ for best accuracy, this is important!
Check how $\cos \phi$ influences Up- time.

For more information refer to the DPI Sizing guide.

[DPI Sizing Guide](#) (166kb)

A 3-page document that details methods to determine the correct size DPI for your application, examples included.

If you would like to have a quotation for the units that are selected tick the check box for the desired model, select or deselect the Bypass Switch as required, then click the "Add to Quotation" button. On the next page you can specify quantities, add more items and request a quotation. Please be sure to fill in all the fields on the information form. Then click "Request Quotation". We will e-mail the quotation to the address provided within 24 hours.

Model	Up-Time (sec)	Select	Add Bypass Switch? (Optional)
DPI152L3k12	1.57	<input type="checkbox"/>	<input checked="" type="checkbox"/> BPSW-40
DPI152L2k12 ★	1.05	<input type="checkbox"/>	<input checked="" type="checkbox"/> BPSW-40

Select the DPI152L2K12 with up-time of 1.05 seconds.

2. Use the Minimum up-time formulae

Refer to the *Specifications* section in the user manual, look for the formulae under the heading *Inverter*, sub heading *Minimum up-time as a function of the load*.

Guidelines for sizing a DPI

Minimum up-time as function of the load: $t = (\eta * C_{cap} * V_{supply}) \div (I_{load} * \cos \Phi)$

Minimum up-time = t

Value of storage capacitor(s) = C_{cap}

Stored energy factor = η

Load voltage = V_{supply}

Load current = I_{load}

Load power factor = $\cos \Phi$

use default (1 sec) or choose a value.

see specification for model selected.

see specification for model selected.

measure or estimate value.

measure or estimate value.

measure or estimate value.

Pick a DPI with a VA rating close to the application VA rating then enter the capacitor value and stored energy figures from the DPI specification sheet together with the load data. Compare the Minimum up-time result with the required up-time for the application. If the up-time is too low recalculate using the next largest DPI if the up-time is too large recalculate with the next smaller DPI.

Example

Application data:

$$t = 1 \text{ second} / V_{supply} = 120V / I_{load} = 10A / \cos\Phi = 0.2$$

Load VA = 1200 try a DPI52L1K12

DPI data from specifications: $C_{cap} = 0.022 / \eta = 0.38$


Minimum up-time = $(0.38 * 0.022 * 120) \div (10 * 0.2) = 0.50$ seconds - too low!

Try DPI52L2K12

DPI data from specifications: $C_{cap} = 0.044 / h = 0.39$

Minimum up-time = $(0.39 * 0.044 * 120) \div (10 * 0.2) = 1.03$ seconds - OK!

Select the DPI52L2K12 for the application.



A typical DPI connection diagram

Fig 1
On site measurement of load parameters